



# OASIS Furniture Care

To extend the life of your new outdoor furniture, we recommend that it not be exposed to long hours of direct sunlight or harsh elements. Proper cleaning and storage is also recommended.

## **WOOD CARE:**

A natural color change will occur with all timbers due to aging and seasoning. Surface cracks may appear over time but do not affect the structural strength of the furniture. Wood should be cleaned regularly with a diluted mild detergent and wiped dry with a clean cloth. Remove any spills or deposits that could stain the furniture as soon as possible. Do not use abrasive substances, pads, or brushes, which could degrade the surface finish.

Avoid anything that exposes your furniture to constant wetting. Remove wet cushions or towels, do not wrap in covers that will hold moisture on the surface, and make sure the furniture is not under dripping parasols or leaking gutters.

Do not store your furniture in centrally heated rooms, as this will cause the timber to dry out and possibly shrink. Cool, well-ventilated areas are most suitable. Annual maintenance with hardwood oil is recommended before each new season.

## **SUPER STONE CARE:**

Each super stone top will slightly vary in color, markings, veins, and texture. Maintaining the factory seal is essential to prevent staining, so annual maintenance of the seal with an appropriate masonry sealer is highly recommended. Wipe up liquid spills to prevent permanent staining. Avoid using solvents or abrasives on the table surface.

## **METAL CARE:**

Powder-coated metal frames can be affected by salt, chlorine, chemicals, dirt, and grime, so a regular cleaning is recommended. Clean the frames with warm soapy water and rinse with clean water. Wipe the surface with a soft cloth to dry. Do not use abrasive materials, or cleansers, as this will damage the finish. Make sure to drain any water accumulated inside the frames before storing them for winter.

## **ROPE CARE:**

Brush off any loose dirt and dust regularly when dry, and remove stains promptly to prevent permanent marking. To clean, sponge lightly with a mild solution of natural soap and lukewarm water. Remove red wine immediately by soaking it up with household baking soda and vacuum it off when dry. To remove stubborn stains, wash rope with a solution of a quarter cup of mild detergent and water and rinse thoroughly with clean water. Do not bleach, dry clean, or use any solvent-type cleaners.

## **WICKER CARE:**

Wicker is a high-quality human-made material that is resistant to mildew, staining, and cracking. It is very durable and ideal for most climates. Regularly brush off any dirt and debris with a soft, dry cloth. If a deeper cleaning is needed, use a damp cloth with mild soap and dry thoroughly.